

Essentials 3 lever deadlock (J-ES-DL) installation instructions and template



Issue 2 (October 22)

General view of main parts

Locking plate

Deadlock

Key(s)

Tools

Scissors

Pencil

Masking tape

Bradawl

Cross head screwdriver

16mm chisel

Mallet

Ø10 and Ø16mm drill

1a

Cut out lock templates

1b

Mark centreline of door and frame.
At required height mark a horizontal line on door and frame.

2

Using the centreline guide and height guide, tape templates to door.
Mark the centres of all holes with a bradawl then remove template.

3

Ø16mm
A

65mm Lock	Dim 'A'
79mm Lock	73mm
	88mm

4a

Chisel out remaining timber between drill holes.

4b

5a

Mark and chisel 2mm for faceplate so it is flush.

5b

6

Ø16mm
Ø10mm
B

65mm Lock	Dim 'B'
79mm Lock	45mm
	58mm

7

Chisel out remaining timber between holes, and remove any sawdust.

8

Secure strike plate template to frame with tape. Using a bradawl mark all centres (+). Then remove template.

9

Ø16mm
25mm

10a

Chisel out remaining timber and remove any sawdust.

10b

11a

Strike plate to be flush

11b

12

Fix into position

13

Use remaining fixings to install the lock into the door.

14

3 lever deadlock template

