



WIRING DIAGRAM

EL460, EL461, EL462, EL463,
EL560, EL561, EL562, EL563
EL260, EL262, EL360, EL362



Micro switches of lock case when:


- Key cylinder not used
- Handle not used
- Bolt out
- Trigger bolt in
- Bolt not in



WARNING!

Do not use handle down indication to lock's control. It is made for access control and prevention of the burglary alarm.

*) not micro switch locks



**) Potential free loop is closed when connection cable is connected to lockcase.

Copyright © Abloy Oy Joensuu Factory 2008

